






Ultimate Service Area	486 square miles
Ultimate Service Area Bay	93 square miles
Ultimate Service Area Land	393 square miles
Service area including Bay	
Current Service Area (not-served)	9.5 square miles
Current Service Area (served)	408 square miles
Service area not including Bay	
Current Service Area (not-served)	9.5 square miles
Current Service Area (served)	331 square miles

EBMUD ServiceArea SERVED

-  Not_Served
-  Current Service

SYMBOL

-  Bay within USB
-  Land within USB



Attachment C2- EBMUD Water Supply System/Place of Use

FIGURE 1-1

EBMUD SERVICE BOUNDARY

